

2150 & 2195 setting Limits using 2160 Motor

Start blind in downward direction using switch. When blind reaches approximately $\frac{1}{2}$ m above required down position, press "down" limit button firmly with a screwdriver. When required position reached, release "down" limit button. Motor will stop and remember this position. If you overshoot, raise blind to approximately $\frac{1}{2}$ m above the required position and repeat above.

Up limit is set as above but using "up" switch and up "limit".

Note - Motor is not rated for continuous operation, thermal cut out may come into operation if motor is continuously run during setting of limits. Leave blind for approximately 20 minutes to allow motor to cool and the thermal cut out to automatically reset.

