11092 Timer unit Setting the CLOCK TIME



<u></u>	Press for 3" to unlock the Timer Control - wait for the unit to respond before moving to the next step.
ტ	Press for a further 3" to enter Programming Mode the Clock Symbol (top left) flashes.
	Press to select the Clock setting - 24 hour clock.
	Press to change Hour Number - Forwards or Backwards .
>	Press to move from Hour to Minutes setting.
	Press to change Minutes Number - Forwards or Backwards .
>	Press to move from Day setting.
	Press to change the Day of the Week - Forwards or Backwards .
Û	When finished, Press (b for 3" to SAVE settings.

11092 Timer unit

Supplied by SILENTGLISS SPARES SILENTGLISS SYSTEMS www.sg-s.co.uk email: sales@sg-s.co.uk tel: 01395 232528

Setting the TIMER

<u></u>	Press for 3" to unlock the Timer Control - wait for the unit to respond before moving to the next step.
<u></u>	Press for a further 3" to enter Programming Mode .
>	Press to move to move to the Timer Mode the Timer Clock Symbol flashes.
	Press to select Timer Letter - A (1st timer setting) or B (2nd timer setting) or C (3rd timer setting), etc
	Press to change Timer Letter - forwards A , B , C or backwards C , B , A .
>	Press to move to ON/OFF setting.
	Press to change Timer setting to ON or OFF .
>	Press to move to Hour setting.
	Press to Advance Hour time Forwards or to move Hour Time Backwards .
>	Press to move to Minutes setting.
	Press to Advance Minute time Forwards or to move Minute Time Backwards .
>	Press to move to Open/Close Curtains setting.
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Press to select Open Curtains (at time selected) or to Close Curtains (at time selected).
	Press to move to Days setting.
$\triangleleft \triangleright$	Press [or $\triangleright \triangleleft$] to move between Days .
	Press to Delete or to Add Days.
Ф	When finished, Press (b for 3" to SAVE settings.